

Instruction Manual

High Frequency Superior Air Ionizer

(KS130H)



Registered at Cardiff No. 2933918
Registered Office: Bondline Electronics, Unit 4,
Rivermead Industrial Estate, Rivermead Drive,
Swindon, Wiltshire, SN5 7EX

Introduction

Thank you for purchasing a KS130H Ionizing Air Ionizer. Please read this instruction manual in great detail before operating.

Description

KS130H High Frequency Superior Air Ionizer is a highly efficient four fan ionizer that ensures a static free work area. The four fans are independent of each other with individual controls and circuitry. Very easy to clean and maintain due to clip-on fan covers. These units have built in auto balance feature (+/-5V) with an out-of-balance alarm. All ionizers are CE approved. Size: 1200 x 145x65mm.

Features

- 1) For ionization of a large workstation.
- 2) The device provides excellent ion balance and high efficient static elimination. It can rapidly eliminate static charges for both near-by and distant objects. The device can maintain its special ascendant performance even after long use.
- 3) The device offers power supply input indication function (power supply switch indicator light), ionization indication function (green indicator light) and high volt power supply abnormality indication function (red indicator light).
- 4) The device has self-regulation of positive and negative ions. It persistently and automatically maintains its ascendant ion balance function. Regular ion balance rectification is not necessary.
- 5) The discharge needle is made of special alloy, which makes its discharge stability and wear resistance much stronger than those of tungsten one. This persistently stabilises its ionization and ion balance function.
- 6) Assembly and disassembly of the front louver is easy. Maintenance of the device and cleaning of the electrode can be performed with ease.
- 7) Adjustable blowing angle and air volume.

Packing List

Make sure each of the following items are included in the pack.

- | | |
|---------------------------------|---|
| 1) Main Unit..... | 1 |
| 2) Mains Power Supply Lead..... | 1 |
| 3) Fixing Holders..... | 1 |
| 4) Instruction Manual..... | 1 |

Specifications

Technical information providing the specifications of the High Frequency Superior Air Ionizer.

Power Supply Voltage	AC100~240V 50/60Hz
Capacity	48VA
HV Output Voltage	AC2200V
Ion Balance	Auto ion balance, 0±5V
Air Volume	5.2~13m ³ /min
Ozone Density	Less than 0.007ppm
Allowable Humidity	25~70%RH (no drops)
Allowable Temperature	0~40°C

Abnormal HV alarm

The high voltage power supply alarm indicator light illuminates when the high voltage power supply abnormally discharges as follows:

- 1) The high voltage has a low output;
- 2) The high voltage has a short circuit;
- 3) The high voltage discharges abnormally.

Ionization Performance

The ionization performance is tested according to American EOS/ESD-STM3. 1-2000 standard. References are as follows:

Specifications	
Effective Distance (mm)	600mm × 1220mm
Ion Balance (V)	Within 0±5V
Decay Time (sec)	±1000V→±100V within 2.5 (sec)

Note: The testing figures will vary due to different testing conditions. The test distance is 450mm.

Operating Location

After fixing the main unit with the fixing holders, you can hang the blower with a metal chain or fix it on the frame overhead the workstation. Choose the suitable blowing angle. Do not operate the device under inflammable or explosive atmospheres. In addition, do not insert any object through the air inlet louver. Keep it unobstructed.

Usage

- 1) Install the main unit and the fixing holder.
- 2) Put the fixing rubber pads between the main unit and the stand, then adjust the angle and tighten the knob bolt. The device can be used both on desk and on machines or product lines by using the mounting holes (3-φ4.5).
- 3) Connect the accessory power cord output terminal to the main unit, and then plug it in the AC power supply socket. (Caution: Do not use other DC regulated power supply at will.)
- 4) After the main unit is on, the electrodes will emit corona discharge and a great amount of ionized air is generated. Thereby, a great amount of ionized airflow is blown off by the fan through the front louver. The charged object in ionization area will be neutralised immediately.
- 5) The ionized airflow is adjustable by turning the knob.
- 6) The device offers auto balance of positive and negative ions. No adjustment is necessary.
- 7) The red alarm indicator light illuminates when the high voltage power supply abnormally outputs. Turn the power supply off and check the problem, and then turn the power on after debugging.
- 8) Turn the power switch off after using.

Daily Maintenance

Cleaning of the front louver:

Disassemble the front louver by pressing the side wrench inwardly. Clean it with a cotton swab or water it with neutral washer. Assemble it when it is dry.

Cleaning of the discharge needle:

Dust and contamination will drift around the tip of the discharge needle after long use. Clean the discharge needle with a cotton swab. Periodical cleaning is necessary (once every 100 hours. If the discharge needle is dusty, clean it with an included cotton swab and alcohol. Do not damage or loosen the discharge needle. Be careful with your fingers when cleaning.

Disassemble of the discharge needle:

When you need to replace the discharge needle, please press and rotate the needle base in a clockwise direction. Use a tool to press the end of the needle to loose it and take it out .Put on the new needle and rotate the needle base in a counterclockwise direction.

Cleaning of the filter:

Water it with neutral washer. Assemble it when it is dry.